



SPI is just there for programming normally the interface operates in two-wire mode, making MISO <= SDA and SCK <= SCL.

TITLE: dsplabor_displayBoard

Document Number: _____ REV: _____

Date: 13.01.19 16:39 Sheet: 1/1