



SPI is just there for programming normally the interface operates in two-wire mode, making MISO <= SDA and SCK <= SCL	
TITLE: dsplabor_displayBoard	
Document Number:	REV:
Date: 13.01.2019 16:39	Sheet: 1/1